



KENNETH LYNCH & SONS

Est. 1927

#6736 WORLD'S FAIR BACKLESS BENCH ASSEMBLY INSTRUCTIONS NATURAL WOOD

Unpack and verify parts count.

8'L	3x legs	1x tie rod, 93" long 4x large nuts	7x slats, 8' long	42x 1/4"- 20x 2 1/8" carriage bolts 42x flat washers & nuts
6'L	2x legs	1x tie rod, 69" long 4x large nuts	7x slats, 6' long	28x 1/4"- 20x 2 1/8" carriage bolts 28x flat washers & nuts
4'L		1x tie rod, 45" long 4x large nuts	7x slats, 4' long	

Tools required: Hammer, 7/16" wrench or socket. 15/16" wrench or adjustable wrench.

1. Stand the legs up and install the tie rod with large nuts on both sides of the legs, leaving all loose for the time being.
2. Install all the slats of wood on the seat using the 2" long bolts. Leave the nuts loose.
3. Now, keeping the bench legs all square and plumb and making sure that all the slat ends are even, tighten all the nuts. When you tighten the nuts watch to make sure that you don't tighten them so much that the bolt heads are drawn into the surface of the slat which can happen easily with softer wood. Tighten the bolts evenly on both sides of the leg so that one bolt doesn't make the bench stand crooked.
4. Touch up the nuts at the tie rod and anywhere paint has chipped off from handling. This completes the assembly.



FLORENTINE
Classics

