

6736C WORLD'S FAIR BACKLESS BENCH ASSEMBLY INSTRUCTIONS NATURAL WOOD

Unpack and verify parts count.

8'L	3x legs, 3 armrests	1x tie rod, 93" long 4x large nuts	7x slats, 8' long	18x 2 1/8" carriage bolts 24x 2 ½" security bolts 24x black plastic washers 42x flat washers & nuts
6'L	2x legs, 2 armrests	1x tie rod, 69" long 4x large nuts	7x slats, 6' long	12x 2 1/8" carriage bolts 16x 2 ½" security bolts 16x black plastic washers
4'L		1x tie rod, 45" long 4x large nuts	7x slats, 4' long	28x flat washers & nuts

Tools required: Hammer, 7/16" wrench or socket. 15/16" wrench or adjustable wrench, security bit and driver.

- 1. Stand the legs up and install the tie rod with large nuts on both sides of the legs, leaving all loose for the time being.
- 2. Install the middle slats of wood on the seat using the 2 1/8" long bolts. Leave the nuts loose.
- 3. Place the outside slats of wood on the seat and then place the arm rests on top of the wood. Use the 2 ½" long bolts to attach the armrest, wood and bench leg together. The arm rest, wood and bench leg drilling all line up together, no additional holes are required.
- 4. Get a straight 2x4 and set it against the feet of the legs so one foot of each leg is touching the 2x4. This way you can make sure that the legs are lined up. Now, using a 2' framing square, check to see that the legs are at right angles to the 2x4. Also check to see that the legs are plumb. Of course, you must be working on a level floor.
- 5. Now, keeping the bench legs all square and plumb and making sure that all the slat ends are even, tighten all the nuts. When you tighten the nuts watch to make sure that you don't tighten them so much that the bolt heads are drawn into the surface of the slat which can happen easily with softer wood. Tighten the bolts evenly on both sides of the leg so that one bolt doesn't make the bench stand crooked.
- 6. Touch up the nuts at the tie rod and anywhere paint has chipped off from handling. This completes the assembly.





